

AMP RESEARCH
2552 McGaw Ave
Irvine, CA 92614
1-888-983-2206
amp-research.com


AMP RESEARCH Power Step

Nationally Distributed by Bestop

ONE EASY STEP. Climbing in and out of today's full-size pickups and SUVs can be a challenge for some people, but now there's a solution – the AMP RESEARCH POWER STEP. Open the door and Power Step automatically deploys to the just-right height for easy stepping. Close the doors and this sure-footed step platform retracts safely under the truck out of sight.

Heavy duty motor and drive system with anti-pinch technology. Activated by the vehicle's factory door sensors.

High-strength aluminum boards deliver sure-footed stepping for both driver and passengers.



Retracts safely under the vehicle with no loss of ground clearance. Proven to perform in severe driving conditions. Backed by a three-year limited warranty.

APPLICATIONS	MODEL YR	PART N ^o	NOTE
GM			
Chevy Silverado / GMC Sierra Extended Cab	2007 +	10-03419-72	NEW
Chevy Silverado / GMC Sierra Crew Cab	2007 +	10-03419-79	NEW
Chevy Silverado / GMC Sierra Extended Cab	1999-2007 Classic	10-03057-11	(1)
Chevy Silverado / GMC Sierra Crew Cab	1999-2007 Classic	10-03057-10	(1)
Chevy Tahoe / GMC Yukon	2001-2006	10-03036-11	(1)
Chevy Tahoe / GMC Yukon	2007 +	10-03274-72	NEW
Chevy Suburban / GMC Yukon XL	2001-2006	10-03036-10	(1)
Chevy Suburban / GMC Yukon XL	2007 +	10-03274-79	NEW
Chevy Avalanche (with cladding)	2000-2006	10-03036-11	(1)
Chevy Avalanche (w/o cladding)	2000-2006	10-03036-10	(1)
Chevy Avalanche	2007 +	10-03274-79	NEW
Cadillac Escalade	2002-2006	10-03036-11	(1)
Cadillac Escalade	2007 +	10-03274-72	NEW
Cadillac Escalade EXT / ESV	2002-2006	10-03036-10	(1)
Cadillac Escalade EXT / ESV	2007 +	10-03274-79	NEW
HUMMER [®] H2	2003-2007	10-02924-11	
HUMMER [®] H2 SUT	2004-2007	10-02924-11	
HUMMER [®] H3	2005-2007	10-03221-10	
(1) DIODES REQUIRED. GM trucks and SUVs, model years 1999-2002, require four (4) additional diodes that are not included in the standard parts kit – When ordering please specify the vehicle model year so that the diodes can be included. If needed, additional diodes (Part #10-02727-90) may be ordered at no charge and shipped UPS Ground by calling 1-800-983-2206.			
FORD			
Ford Super Duty F-250 / F-350 Regular Cab	2008 +	10-03472-48	NEW
Ford Super Duty F-250 / F-350 Super Cab	2008 +	10-03472-60	NEW
Ford Super Duty F-250 / F-350 Crew Cab	2008 +	10-03472-79	NEW
Ford Super Duty F-250 / F-350 Regular Cab	1999-2007	10-02513-24	(2)
Ford Super Duty F-250 / F-350 Super Cab	1999-2007	10-02513-25	(2)
Ford Super Duty F-250 / F-350 Crew Cab	1999-2007	10-02513-26	(2)
Ford Excursion	2000-2005	10-02513-26	
Ford F-150 Super Cab	2004-2007	10-02996-11	
Ford F-150 Super Crew	2004-2007	10-02996-12	
Lincoln Mark LT	2006 +	10-02996-12	
Ford F-150 Super Crew (Heritage)	1999-2004	10-02996-13	
(2) DIODES REQUIRED. 2004-2006 Ford Super Duty trucks <u>without</u> remote keyless plus 2001 and older Super Duty trucks <u>with</u> remote keyless entry require four (4) additional diodes that are not included in the standard parts kit – When ordering please specify the vehicle model year so that the diodes can be included. If needed, additional diodes (Part #10-02727-90) may be ordered at no charge and shipped UPS Ground by calling 1-800-983-2206.			
DODGE			
Dodge Ram Quad Cab 1500 / 2500 / 3500	2002-2007	10-02770-11	
Dodge Ram Mega Cab 1500 / 2500 / 3500	2006-2007	10-02770-13	
JEEP[®]			
Wrangler & Wrangler Unlimited (TJ)	2003-2006	10-03315-10	
NISSAN			
Nissan Titan Crew Cab / Armada / Infiniti QX65	2004-2007	10-03074-10	
Nissan Titan King Cab	2004-2007	10-03074-11	
2" EXTENSION KIT (Recommended for lifted trucks)			
Works best with Ford Super Duty and Dodge Ram		80-03093-90	
DIODE KIT (Required for some applications)			
Diode Kit (4 single diodes per kit)		10-02727-90	
LIGHT KIT			
L.E.D Light Kit (Compatible with new style controller only)		10-03303-90	NEW